







BRN ABROSRO. VÁCLAVA KULÍŠKA 1224, 686 05 UHERSKÉ HRADIŠTĚ, CZECH REPUBLIC

*phone.:* +420 773 984 338 www.brmaero.com















ILS/A

Date of Issue: 07/2011













**Registration:** 

Serial Number:

Rotax 914 UL powered Bristell with 27 foot performance wing

R 7-16-2015

Date of Issue: 07/2011













This airplane must be operated in compliance with information and limitations contained in herein. This AOI must be available on board of the airplane.













# **SECTION 0**

# 0. TECHNICAL INFORMATION

- 0.1 Record of revisions
- 0.2 List of effective pages
- 0.3 Table of contents

Date of Issue: 07/2011

























### 0.1 Record of revisions

Any revision of the present manual (except actual weighing data, cockpit description and list of instruments and avionics) must be recorded in the following table.













Revision No.	Affected Section	Affected Pages	Date of Issue	Approved by	Date of approval	Date inserted	Sign.
1	ALL	ALL, Initial	7/2011	Milan Bristela	7/2015	7/2015	

Date of Issue: 07/2011















ST









0.2 List of effective pages

Section	Page	Date of Issue		Section	Page	D	ate of Issu	е	
			0	0-1	07/2011		3	3-1	07/2011
				0-2	07/2011			3-2	07/2011
				0-3	07/2011			3-3	07/2011
				0-4	07/2011			3-4	07/2011
				0-5	07/2011			3-5	07/2011
				0-6	07/2011			3-6	07/2011
								3-7	07/2011
			1	1-1	07/2011			3-8	07/2011













Section	Page	Dat	te of Issue	Section	Page	D	ate of Issu	ie		
				1-2	07/2011				3-9	07/2011
				1-3	07/2011					
				1-4	07/2011					
				1-5	07/2011					
				1-6	07/2011					
			2	2-1	07/2011		4		4-1	07/2011
				2-2	07/2011				4-2	07/2011
				2-3	07/2011				4-3	07/2011

Date of Issue: 07/2011

Revision: 1.0

### 0-10













Section	Page	Daf	te of Issue	Section	Page	D	ate of Issue	е	
				2-4	07/2011			4-4	07/2011
		ļ		2-5	07/2011			4-5	07/2011
		ļ		2-6	07/2011			4-6	07/2011
		ļ		2-7	07/2011			4-7	07/2011
		ļ		2-8	07/2011			4-8	07/2011
		ļ		2-9	07/2011			4-9	07/2011
		ļ						4-10	07/2011
		ļ						4-11	07/2011
		ſ							













Section	Page	Page Date		Section	Page	D	ate of Iss	ue		
			5	5-1	07/2011		7		7-1	07/2011
				5-2	07/2011				7-2	07/2011
				5-3	07/2011				7-3	07/2011
				5-4	07/2011				7-4	07/2011
				5-5	07/2011				7-5	07/2011
				5-6	07/2011				7-6	07/2011
				5-7	07/2011				7-7	07/2011
									7-8	07/2011

Date of Issue: 07/2011

Revision: 1.0

### 0-12













Section	Page	Page Date of Iss		Section	Page	D	Date of Issue			
									7-9	07/2011
			6	6-1	07/2011					
				6-2	07/2011		8		8-1	07/2011
				6-3	07/2011				8-2	07/2011
				6-4	07/2011				8-3	07/2011
				6-5	07/2011				8-4	07/2011
				6-6	07/2011					
				6-7	07/2011		9		9-1	07/2011

Date of Issue: 07/2011

Revision: 1.0

### 0-13













Section	Page	Da	te of Issue	Section	Page	D	ate of Issu	le		
				6-8	07/2011				9-2	07/2011
				6-9	07/2011				9-3	07/2011
				6-10	07/2011				9-4	07/2011
				6-11	07/2011				9-5	07/2011
				6-12	07/2011					
							10		10-1	07/2011
									10-2	07/2011
									10-3	07/2011
									10-4	07/2011













0.3 Table of contents

TECHNICAL INFORMATION	Section0
GENERAL INFORMATION	1
OPERATING LIMITATIONS	2
EMERGENCY PROCEDURES	3
NORMAL PROCEDURES	4
Date of Issue: 07/2011	Revision: 1.0
0-	

15













PERFORMANCE	5
WEIGHT AND BALANCE	6
AIRPLANE AND SYSTEMS DESCRIPTION	7
AIRPLANE HANDLING, SERVICING AND MAINTENANCE	8
REQUIRED PLACARDS AND MARKINGS	. 9
SUPPLEMENTS	10

Date of Issue: 07/2011

























# **SECTION 1**

# **1. GENERAL INFORMATION**

- 1.1 Introduction
- 1.2 Warnings, cautions and notes
- 1.3 Descriptive data
  - 1.3.1 Aircraft description
  - 1.3.2 Powerplant
  - 1.3.3 Aircraft dimensions

Date of Issue: 07/2011













1.3.4 Aircraft layout 1.4 Definitions and abbreviations













### 1.1 Introduction

BRISTELL LSA is an LSA Aircraft built in BRM AERO s.r.o., Uherske Hradiste, Czech Republic, based on czech LAA UL 2 Standards, CS-VLA Standards and FAA Light Sport Aircraft (LSA) category according to ASTM Standards F2245, F2279 and F 2295.

This Aircraft Operating Instruction has been prepared to provide pilots with information for the safe and efficient operation of BRISTELL LSA aircraft. It also contains supplemental data supplied by the Aircraft Flight Training Supplement.













### 1.2 Warnings, cautions and notes

The following definitions apply to warnings, cautions and notes in the Pilot Operating Handbook.

#### WARNING

Means that the non-observation of the corresponding procedure leads to an immediate or important degradation of the flight safety i.e. to injury or death of persons.

#### CAUTION

Date of Issue: 07/2011



ST









Means that the non-observation of the corresponding procedure leads to a minor or possible long term degradation of the flight safety.

#### NOTE

Draws attention to any special item not directly related to safety, but which is important or unusual.

### 1.3 Descriptive data

#### 1.3.1 Aircraft description

BRISTELL LSA is airplane intended especially for recreational and crosscountry flying, non-aerobatics operation and basic training.

Date of Issue: 07/2011













BRISTELL LSA is a single-engine, all metal, low-wing monoplane of semimonocoque construction with two side-by-side seats. The airplane is equipped with a fixed tricycle undercarriage with steerable nose wheel.

#### 1.3.2 Powerplant

Powerplant is the ROTAX 914 UL 113HP Turbo Charged engine, 4cylinder, 4-stroke engine and DUC ground adjustable three blade propeller and optional Sensenich 3B0R5R68C 1730MM (68") with 3 blades. The prop pitch must be set to avoid exceeding the max 120KCAS limit and to avoid engine overspeeds which can damage the engine.

#### 1.3.3 Aircraft dimensions

Wing span	29,95 ft
Length	21,10 ft

Date of Issue: 07/2011













Height	7.48 ft
Wing area	126,48 sq ft
Wing loading	10.45 lbs/sq ft
Cockpit width	51,17 in

#### **1.3.3PW Performance Wing Aircraft dimensions**

Wing span	27 ft
Length	21,10 ft
Height	7.48 ft
Wing area	113.94 sq ft
Wing loading	11.58 lbs/sq ft
Cockpit width	51,17 in

Date of Issue: 07/2011













#### **Deflection:**

Rudder deflections	.30° to each side
Elevator deflections	.+ 30°/- 15°
Aileron deflections	.+ 24°/-16°
Flap deflections	.0°, 10°, 20°and 30°
Aileron trim deflections	.+ 15°/- 20°
Elevator trim deflections	.+ 10°/- 25°













#### 1.3.4 Aircraft layout (The Performance wing is 27 feet)



























### 1.4 Definitions and abbreviations

- ATC Air Traffic Control
- ASI Airspeed Indicator
- BEACON anti-collision beacon
- CAS Calibrated Airspeed
- COMM communication transmitter
- EFIS Electronic Flight Instrument System
- ELT Emergency Locator Transmitter

Date of Issue: 07/2011













EMS	Engine Monitoring System
°F	temperature in degree of Fahrenheit
ft	foot / feet
ft/min	feet per minute
GPS	Global Positioning System
hp	power unit
IAS	Indicated Airspeed
IC	Intercom
IFR	Instrument Flight Rules
in	inch

Date of Issue: 07/2011













ISA	International Standard Atmosphere
knot	NM per hour
lb	pound
MAC	Mean Aerodynamic Chord
max.	maximum
min.	minimum or minute
mph	statute miles per hour
NM	Nautical Mile
OFF	system is switched off or control element is in off-position
ON	system is switched on or control element is in on-position

Date of Issue: 07/2011













OAT	Outside Air	Temperature

- POH Pilot Operating Handbook
- psi pound per square inch pressure unit
- rpm revolutions per minute
- sec. second
- US gal volume unit
- VFR Visual Flight Rules
- VMC Visual Meteorological Conditions
- V<sub>A</sub> maneuvering airspeed
- VFE maximum flap extended speed

Date of Issue: 07/2011













- V<sub>NO</sub> maximum designed cruising speed
- V<sub>NE</sub> never exceed speed
- Vso stall speed with wing flaps in extended position
- Vs1 stall speed with wing flaps in retracted position
- Vx best angle of climb speed
- Vy best rate of climb speed













# **SECTION 2**

## 2. OPERATING LIMITATION

- 2.1 Introduction
- 2.2 Airspeed
- 2.3 Airspeed Indicator Markings
- 2.4 Powerplant
  - 2.4.1 Engine operating speeds and limits
  - 2.4.2 Fuel

Date of Issue: 07/2011













- 2.4.3 Oil
- 2.4.4 Coolant
- 2.5 Powerplant Instrument Markings
- 2.6 Miscellaneous Instrument Markings
- 2.7 Weight
- 2.8 Center of Gravity
- 2.9 Approved Maneuvers
- 2.10 Maneuvering Load Factors
- 2.11 Crew
- 2.12 Kinds of Operation

Date of Issue: 07/2011













### 2.13 Other Limitations

### 2.1 Introduction

Section 2 includes operating limitations, instrument markings and basic placards necessary for the safe operation of the aircraft, its engine, standard systems and standard equipment.

Date of Issue: 07/2011












## 2.2 Airspeed

Airspeed limitations and their operational significance are shown below:

Speed		KIAS	Remarks		
V <sub>NE</sub>	Never exceed speed	145	Do not exceed this speed in any operation.		













V <sub>NO</sub>	Max. structural cruising speed	115	Do not exceed this speed except in smooth air, and then only with caution.
V <sub>A</sub>	Maneuvering speed	89	Do not make full or abrupt control movement above this speed, because under certain conditions full control movement may overstress the aircraft.
V <sub>FE</sub>	Maximum Flap Extended Speed	75	Do not exceed this speed with flaps extended.

Date of Issue: 07/2011













## 2.3 Airspeed indicator markings

Airspeed indicator markings and their color-code significance are shown below:

Marking	IAS value or range	Significance	
Marking	Knots		
White arc	39-75	Flap Operating Range.	
Green arc	43-115	Normal Operating Range.	

Date of Issue: 07/2011













Yellow arc	115-145	Maneuvers must be conducted with caution and only in smooth air.
Red line	145	Maximum speed for all operations.

























### 2.4 Powerplant

#### 2.4.1 Engine operating speeds and limits

The prop pitch must be set to assure the 120 KCAS legal LSA limit is not exceeded and to protect the engine from overspeeds.

Engine Model:		ROTAX 914 UL Turbo
Engine Manufacturer:		Bombardier-Rotax GMBH
	Max Take-off:	113 hp at 5800 rpm, max.5 min.
Power	Max. Continuous:	98.5 hp at 5500 rpm
	Cruising:	75 hp at 5100 rpm

Date of Issue: 07/2011













RPM	Max. Take-off:	5800 rpm, max. 5 min.
	Max. Continuous:	5500 rpm
ngine	Cruising:	5100 rpm
ш	Idling:	~1400 rpm
ider head berature:	Minimum:	-
	Maximum:	248 / 275° F *
Cylir tem	Optimum:	176 - 230° F
ii ierat 'e	Minimum:	122° F
o temp	Maximum:	266° F

Date of Issue: 07/2011













	Optimum:	176 - 230° F	
ure:	Minimum:	12 psi <i>- below 3500 rpm</i>	
ress	Maximum:	102 psi - cold engine starting	
i liO	Optimum:	29,2 - 73 psi - above 3500 rpm	
* Max. CHT temperature depend on the type of coolant used in engine. - see Section 2.4.4 and Section 10 Supplement No.2			













#### 2.4.2 Fuel

This fuel can be used: (refer to engine Operator's Manual)

- min. RON 95, EN 228 Premium, EN 228 Premium plus, AVGAS100LL
- Fuel according to FAA Standard Spec. for Automotive Spark-Ignition Engine Fuel, ASTM D 4814 or AVGAS 100 LL
- Fuel according to DOT CAN/CGSB-3.5 Quality 3 min AKI 91 or AVGAS 100 LL, 93 Octane Automotive Fuel

Due to higher lead content in AVGAS, the wear of the valve seats and deposits in the combustion chamber will increase. Therefore, use AVGAS only if you encounter problems with vapor lock or if the other fuel types are not available.













#### Fuel volume:













#### 2.4.3 Oil

#### Oil type:

(refer to engine Operator's Manual)

Use motorcycle a 4 stroke engine oil of registered brand with gear additives, but not aircraft oil. Use only oil with API classification "SG" or higher! Use of multi-grade no mineral oils is recommended.

**NOTE:** Type of oil used by aircrafts manufacturer is shown in Section 10 Supplement No.2.

#### Oil volume:

Minimum......0,856 U.S. gallons Maximum......0,951 U.S. gallons

Date of Issue: 07/2011













#### 2.4.4 Coolant

#### Coolant type:

(refer to engine Operator's and Installation Manuals)

The water-free coolant concentrate can be used based on *propylene glycol*. The conventional glycol/water coolant mixture can also be used. The conventional glycol/water coolant mixture reduce to apply the max.permissible cylinder head temperature.

**NOTE:** Type of coolant used by aircrafts manufacturer is shown in Section 10 Supplement No.2.

#### Coolant liquid volume:

It is about.....0,66 U.S. gallons













#### 2.4.5 Powerplant instrument markings

Analogue engine instruments markings and their color-code significance are shown below.

Rotax 912S 98.6 hp	Minimum Limit (red line)	Normal Operating Range (green arc)	Caution Range (yellow arc)	Maximum Range (red line)
Engine speed [RPM]	1400	1400-5500	5500-5800	5800
Oil Temperature	50°C (122°F)	50-110°C (122-230°F)	110-130°C (230-266°F)	130°C (266°F)

Date of Issue: 07/2011



ST









Exhaust Gas Temp. (EGT)	-	800-850°C (1472- 1562°F)	850-880°C (1562-1616°F)	880°C (1616°F)
Cylinder Head Temperature (CHT)	50°C (122°F)	50-110°C (122-230°F)	110-120 / 135°C * (230-248 / 275°F)	120 / 135°C * (248 / 275°F)
Oil Pressure	0,8 bar (12 psi)	0,8-5 bar (12-73 psi)	5-7 bar (73-102 psi)	7 bar (102 psi) cold engine starting

\* Max. CHT temperature depend on the type of coolant used in engine. - see Section 2.4.4 and Section 10 Supplement No.2

Date of Issue: 07/2011













## 2.5 Miscellaneous Instrument Marking

Note: There are not any miscellaneous instrument marking













## 2.6 Weight

Empty weight (standard equipment)	753 lbs
NOTE	
Actual empty weight is shown in SI	ECTION 6
Max. take-off weight	1320 lbs
Max landing weight	1320 lbs
Max. weight of fuel	190 lbs
Max. baggage weight in rear fuselage	33 lbs
Max. baggage weight in wing lockers	44 lbs each













## 2.7 Center of gravity

Operating C.G. range...... 25 to 35 % of MAC

## 2.8 Approved maneuvers

Airplane Category: ELA, LSA The BRISTELL LSA is approved for normal and below listed maneuvers:

- Steep turns not exceeding 60° bank
- Lazy eights
- Chandelles
- Stalls (except whip stalls)

Date of Issue: 07/2011













#### WARNING

Aerobatics and intentional spins are prohibited!

## 2.9 Maneuvering load factors

Maximum positive limit load factor...+4 g / Negative max ...-2g

## 2.10 Crew

Number of seats	2
Minimum crew	1 pilot in the left seat
Minimum crew weight	121 lbs

Date of Issue: 07/2011

Revision: 1.0

2-21













Maximum crew weight ..... see SECTION 6

WARNING

Do not exceed maximum take-off weight 1320 lbs !

## 2.11 Kinds of operation

There are permitted Day VFR flights, Night VFR flights are permitted with installation of optional Night Lighting Package and operation by an appropriate rated pilot.

WARNING

Date of Issue: 07/2011



ST









IFR flights and intentional flights under icing conditions are PROHIBITED!

#### Minimum instruments and equipment list for VFR flights:

- Airspeed indicator
- Altimeter
- Compass (is not required by ASTM F 2245)
- Fuel quantity indicator
- Tachometer (RPM)
- Oil temperature indicator
- Oil pressure indicator

Date of Issue: 07/2011













- Cylinder head temperature indicator

## 2.12 Other limitations

• No smoking on board of the aircraft!













# **SECTION 3**

# **3. EMERGENCY PROCEDURES**

## 3.1 Introduction

## 3.2 Engine Failure

- 3.2.1 Engine failure during take-off run
- 3.2.2 Engine failure during take-off
- 3.2.3 Engine failure in flight

## 3.3 In-flight Engine Starting

3.4 Smoke and Fire

Date of Issue: 07/2011













- 3.4.1 Fire on ground at engine starting
- 3.4.2 Fire on ground with engine running
- 3.4.3 Fire during take-off
- 3.4.4 Fire in flight
- 3.4.5 Fire in the cockpit
- 3.5 Glide

## 3.6 Landing Emergencies

- 3.6.1 Emergency landing
- 3.6.2 Precautionary landing
- 3.6.3 Landing with a flat tire
- 3.6.4 Landing with a defective landing gear

## 3.7 Recovery from Unintentional Spin

Date of Issue: 07/2011













### 3.8 Other emergencies

- 3.8.1 Vibration
- 3.8.2 Carburetor icing
- 3.8.3. Autopilot malfunction













## 3.1 Introduction

Section 3 provides checklists and amplified procedures for coping with various emergencies that may occur. Emergencies caused by aircraft or engine malfunction are extremely rare if proper pre-flight inspections and maintenance are practiced.

However, should an emergency arise, the basic guidelines described in this section should be considered and applied as necessary to correct the problem.

## 3.2 Engine Failure

#### 3.2.1 Engine failure during take-off run

1. Throttle - reduce to idle

Date of Issue: 07/2011













- 2. Ignition
- switch off
- 3. Apply brakes

#### 3.2.2 Engine failure during take-off

- 1. Speed
- gliding at 65 KIAS
- 2. Altitude
- below 150 ft: land in take-off direction
- -
- 3. Wind
- find direction and velocity

over 150 ft: choose a landing area

- 4. Landing area
- choose free area without obstacles
- 5. Flaps
- extend as needed
- 6. Fuel Selector shut off
- 7. Ignition - switch off

Date of Issue: 07/2011













- 8. Safety harness tighten
- 9. Master switch switch off before landing
- 10. Land













#### 3.2.3 Engine failure in flight

- 1. Push control stick forward
- 2. Speed
- gliding at 65 KIAS
- 3. Altitude - below 150 ft: land in take-off direction over 150 ft: choose a landing area
- 4. Wind
- find direction and velocity
- 5. Landing area
- choose free area without obstacles - extend as needed
- 6. Flaps
- 7. Fuel Selector shut off 8. Ignition

  - switch off
- 9. Safety harness tighten
- 10. Master switch switch off before landing

Date of Issue: 07/2011













#### 11. Land

### 3.3 In-flight Engine Starting

- 1. Electric pump ON
- 2. Fuel Selector switch to second fuel tank
- 3. Starter
- switch on













### 3.4 Smoke and Fire

#### 3.4.1 Fire on ground at engine starting

- 1. Starter
- keep in starting position 2. Fuel Selector - close
- full power 3. Throttle
- 4. Ignition - switch off
- 5. Leave the airplane
- 6. Extinguish fire by fire extinguisher or call for a fire-brigade if you cannot do it.

### 3.4.2 Fire on ground with engine running

1. Heating - close



Aircraft Operating

Instructions











- 2. Fuel selector close
- 3. Throttle
- full power
- 4. Ignition switch off
- 5. Leave the airplane
- 6. Extinguish fire by fire extinguisher or call for a fire-brigade if you cannot do it.

#### 3.4.3 Fire during take-off

- 1. Speed 65 KIAS
- 2. Heating
- close
- 3. Fuel Selector close
- 4. Throttle full power
- 5. Ignition switch off
- 6. Land and stop the airplane

Date of Issue: 07/2011













- 7. Leave the airplane
- 8. Extinguish fire by fire extinguisher or call for a fire-brigade if you cannot do it.



**S**7









#### 3.4.4 Fire in flight

- 1. Heating
- close - close

- full power

- switch off

- 2. Fuel Selector
- 3. Throttle

5. Ignition

- 4. Master switch
  - switch off after the fuel in carburetors is consumed and engine shut down
- 6. Choose of area heading to the nearest airport or choose emergency landing area
- 7. Emergency landing
- ding perform according to 3.6
- 8. Leave the airplane

Date of Issue: 07/2011













9. Extinguish fire by yourself or call for a fire-brigade if you cannot do it.

**NOTE** Estimated time to pump fuel out of carburetors is 30 seconds.

#### WARNING

Do not attempt to re-start the engine!

#### 3.4.5 Fire in the cockpit

- 1. Master switch switch off
- 2. Heating close

Date of Issue: 07/2011













3. Use the fire extinguisher













### 3.5 Glide

An example of the use of gliding is in the case of engine failure

1. Speed - recommended gliding speed 65 KIAS

## 3.6 Landing Emergencies

#### 3.6.1 Emergency landing

Emergency landings are generally carried out in the case of engine failure and the engine cannot be re-started.

- 1. Speed adjust for optimum gliding 65 KIAS
- 2. Trim adjust
- 3. Safety harness tighten
- 4. Flaps extend as needed












- 5. COMM
- if installed then report your location if possible
- 6. Fuel Selector close
- 7. Ignition switch off
- 8. Master switch switch off
- 9. Perform approach without steep turns and land on chosen landing area.

## 3.6.2 Precautionary landing

A precautionary landing is generally carried out in the cases where the pilot may be disorientated, the aircraft has no fuel reserve or possibly in bad weather conditions.

1. Choose landing area, determine wind direction

Date of Issue: 07/2011













- 2. Report your intention to land and land area location if a COMM is installed in the airplane.
- 3. Perform low-altitude passage into wind over the right-hand side of the chosen area with flaps extended as needed and thoroughly inspect the landing area.
- 4. Perform circle pattern.
- 5. Perform approach at increased idling with flaps fully extended.
- 6. Reduce power to idle when flying over the runway threshold and touch-down at the very beginning of the chosen area.
- 7. After stopping the airplane switch off all switches, shut off the fuel selector, lock the airplane and seek for assistance.

[	NOTE	
-		

Date of Issue: 07/2011













Watch the chosen area steadily during precautionary landing.

## 3.6.3 Landing with a flat tire

- 1. During landing keep the damaged wheel above ground as long as possible using the ailerons control
- 2. Maintain the direction on the landing roll out, applying rudder control.

## 3.6.4 Landing with a defective landing gear.

1. If the main landing gear is damaged, perform touch-down at the lowest practicable speed and if possible, maintain direction during landing run.













2. If the nose wheel is damaged perform touch-down at the lowest practicable speed and hold the nose wheel above the ground by means of the elevator control as long as possible.













## 3.7 Recovery from Unintentional Spin

#### WARNING Intentional spins are prohibited!

There is no an uncontrollable tendency of the airplane to enter into a spin provided the normal piloting techniques are used.

Unintentional spin recovery technique:

- 1. Throttle -
- 2. Lateral control ailerons neutralized
- 3. Rudder pedals full opposite rudder

idle













- 4. Rudder pedals rotation stops
- neutralize rudder immediately when
- 5. Longitudinal control neutralize or push forward and recovery dive.













## 3.8 Other Emergencies

## 3.8.1 Vibration

If any forced aircraft vibrations appear, it is necessary:

- 1. To set engine speed to such power rating where the vibrations are lowest.
- 2. To land on the nearest airfield or to perform a precautionary landing according to 3.6

## 3.8.2 Carburetor icing

The carburetor icing shows itself through a decrease in engine power and an increase of engine temperatures.

To recover the engine power, the following procedure is recommended:

1. Speed - 70 KIAS

Date of Issue: 07/2011













- 2. Throttle set to 1/3 of power
- 3. If possible, leave the icing area
- 4. Increase the engine power gradually up to cruise conditions after 1-2 minutes

If you fail to recover the engine power, land on the nearest airfield (if possible) or depending on the circumstances, perform a precautionary landing according to 3.6

#### NOTE

If your engine is equipped with carburetor heating, use it for extended period descent and in area of possible carburetor icing. **Remember:** Aircraft is approved to operate in VMC condition only!

## -----

## 3.8.3 Autopilot malfunction

Date of Issue: 07/2011













In the case, that autopilot starts work not properly, press immediately red button "AP OFF" on the instrument panel.

WARNING Take-Off, climb, Approach and landing with AP "ON" or with malfunction AP are PROHIBITED.













# **SECTION 4**

# 4. NORMAL PROCEDURES

- 4.1 Introduction
- 4.2 Assembly and Disassembly
- 4.3 Pre-flight Inspection

## 4.4 Normal Procedures

- 4.4.1 Before engine starting
- 4.4.2 Engine starting
- 4.4.3 Engine warm up, Engine check

Date of Issue: 07/2011













- 4.4.4 Taxiing
- 4.4.5 Before take-off
- 4.4.6 Take-off
- 4.4.7 Climb
- 4.4.8 Cruise
- 4.4.9 Descent
- 4.4.10 Before landing
- 4.4.11 Balked landing
- 4.4.12 Landing
- 4.4.13 After landing
- 4.4.14 Engine shutdown
- 4.4.15 Aircraft parking
- 4.4.16 Flight in rain













## 4.1 Introduction

Section 4 provides checklists and recommended procedures for normal operation of the aircraft.

## 4.2 Assembly and Disassembly

Refer to the BRISTELL LSA Maintenance and inspection procedures manual.

## 4.3 Pre-flight Inspection

Carry out the pre-flight inspection every day prior to the first flight or after airplane assembly. Incomplete or careless inspection can cause an accident. Carry out the inspection following the instructions in the Inspection Check List.













#### NOTE

The word "condition" in the instructions means a visual inspection of surface for damage deformations, scratching, chafing, corrosion or other damages, which may lead to flight safety degradation.













The manufacturer recommends carrying out the pre-flight inspection as follows:







































## **Inspection Check List**

1	– Ignition	- OFF
	<ul> <li>Master switch</li> </ul>	- ON
	<ul> <li>Fuel gauge ind.</li> </ul>	<ul> <li>check fuel quantity</li> </ul>
	<ul> <li>Master switch</li> </ul>	- OFF
	<ul> <li>Avionics</li> </ul>	- check condition
	<ul> <li>Control system</li> </ul>	<ul> <li>visual inspection, function, clearance, free movement up to stops</li> <li>check wing flaps operation</li> </ul>
	<ul> <li>Canopy</li> </ul>	<ul> <li>condition of attachment, cleanness</li> </ul>
<ul> <li>Check cockpit for loose objects</li> </ul>		cts
2	<ul> <li>Engine cowling condition</li> </ul>	
	<ul> <li>Propeller and spinner conditi</li> </ul>	on



ST









	<ul> <li>Engine mount and exhaust manifold condition</li> </ul>		
	<ul> <li>Oil and coolant quantity check</li> </ul>		
	el and electrical system		
	<ul> <li>Fuel system draining</li> </ul>		
	<ul> <li>Other actions according to</li> </ul>	o the engine manual	
3	<ul> <li>Wing surface condition</li> </ul>		
_	<ul> <li>Leading edge condition</li> </ul>		
	<ul> <li>Pitot head condition</li> </ul>		
(4)	<ul> <li>Wing tip</li> </ul>	<ul> <li>surface condition, attachment</li> </ul>	
-	– Aileron	- surface condition, attachment,	
		clearance,	
		free movement	
	– Flap	- surface condition, attachment,	
		clearance	













5	<ul> <li>Landing gear</li> </ul>	<ul> <li>wheel attachment, brakes, condition and pressure of tires</li> </ul>
	- Wing lower surface and	fuselage bottom surface condition
6	<ul> <li>Vertical tail unit</li> </ul>	<ul> <li>condition of surface, attachment, free movement, rudder stops</li> </ul>
	<ul> <li>Horizontal tail unit</li> </ul>	<ul> <li>condition of surface, attachment, free movement, elevator stops</li> </ul>
	<ul> <li>The check on left side of the fuselage and wing is the same as on right side</li> </ul>	













#### WARNING

Physically check the fuel level before each take-off to make sure you have sufficient fuel for the planned flight.

### CAUTION

In case of long-term parking it is recommended to turn the engine several times (Ignition OFF!) by turning the propeller. Always handle the blade area by the palm i.e. do not grasp only the blade edge. It will facilitate engine starting.













## 4.4 Normal procedures

## 4.4.1 Before engine starting

- 1. Control system
- 2. Canopy
- 3. Brakes
- 4. Safety harness
- free & correct movement
- clean
- fully applied
- tighten

## 4.4.2 Engine starting

- 1. Start the engine according to its manual procedure
- 2. Master switch
  - Selector
- 3. Fuel Selector
- switch on
- or on LEF
- 4. Choke (cold engine)
- on LEFT FUEL TANK !!! - pull to open and gradually release after
- engine start













5. El. pump 6. Starter

- switch on
- hold activated to start the engine

## 4.4.2 914 UL Turbo Charged Engine starting

- 7. Start the engine according to its manual procedure
- 8. Master switch switch on
- 9. Fuel Selector
  - or o
- 10. Throttle

- on LEFT FUEL TANK !!!
- Always start with a closed throttle and gradually increase after engine start

- 11. El. pump
- switch on
- 12. Both Electric starting packs on
- 13. Starter hold activated to start the engine
- 14. Set throttle to 2000 RPM to warm engine.
- 15. After two minutes increase throttle to 2500 RPM to warm engine.
- 16. Note: Engine warm up at idle can cause plugs to foul.

Date of Issue: 07/2011













#### CAUTION

The starter should be activated for a maximum of 10 sec., followed by 2 min. pause for engine cooling.

As soon as engine runs, adjust throttle to achieve smooth running at approx. 2000 rpm. Check the oil pressure, which should increase within 10 sec. Increase the engine speed after the oil pressure has reached 29 psi and is steady.

To avoid shock loading, start the engine with the throttle lever set for idling or 10% open at maximum, then wait 3 sec to reach constant engine speed before new acceleration.

Only one magneto should be switched on (off) during ignition magneto check.

Date of Issue: 07/2011













## 4.4.3 Engine warm up, Engine check

Prior to engine check block the main wheels using chocks. Initially warm up the engine to 2000 rpm for approx. 2 minutes, then continue to 2500 rpm till oil temperature reaches 122°F. The warm up period depends on ambient air temperature.

Switch "ON" propeller control and check propeller adjustment in all adjustment range.

Check both ignition circuits at 4000 rpm for Rotax engine. The engine speed drop during the time either magneto switched off should not over 300 rpm.

#### NOTE

Only one magneto (power pack) should be switched on (off) during ignition magneto check

Date of Issue: 07/2011













Set max. power for verification of max. speed with given propeller and engine parameters (temperatures and pressures).

Check acceleration from idling to max. power. If necessary, cool the engine at 3000 rpm before shutdown.

## CAUTION

The engine check should be performed with the aircraft heading upwind and not on a loose terrain (the propeller may suck grit which can damage the leading edges of blades).













## 4.4.4 Taxiing

Apply power and brakes as needed. Apply brakes to control movement on ground. Taxi carefully when wind velocity exceeds 20 knots. Hold the control stick in neutral position, or in a position that properly deflects a crosswind.













## 4.4.5 Before take-off

- 1. Altimeter
- 2. Trim
- 3. Control system
- 4. Cockpit canopy
- 5. Safety harness
- 6. Fuel Selector
- 7. Ignition
- 8. El. pump
- 9. Propeller control
- 10. Wing flaps
- 11. Autopilot

- set
- set neutral position
- check free movement
- closed
- tighten
- ON (select RIGHT tank first)
- switched on
- ON
- ground set
- 0-10 degrees
- OFF













## 4.4.6 Take-off

- 1. Brakes
- 2. Take-off power
- 3. Engine speed
- 4. Instruments within limits
- 5. Nose wheel unstick add gradual back pressure until nose wheel comes slightly off the ground and release some back pressure. Wait for the plane to fly off the ground

- check

- 6. Airplane lift-off
- 7. Wing flaps

- When ready approximately 45 KIAS

- apply to stop wheel rotation

- check rpm-about 5100 RPM

- throttle fully forward

- retract when speed of 70 KIAS is reached, at altitude of 150 ft
- 8. Transit to climb

Date of Issue: 07/2011













#### WARNING

The Take-off is prohibited if:

- The engine is running unsteadily
- The engine instruments values are beyond operational limits
- The crosswind velocity exceeds permitted limits (see 5.2.8)
- Autopilot is "ON"













## 4.4.7 Climb

- 1. Best rate-of-climb speed
- 2. Throttle
- 3. Trim
- 4. Instruments

- Vy-70 KIAS
- Max. take-off power (max. 5800 rpm for 5 minutes)
- Max. cont.power 5500 rpm
- trim the airplane
- oil temperature and pressure, cylinder temperature within limits

## CAUTION

If the cylinder head temperature or oil temperature approach their limits, reduce the climb angle to increase airspeed and thus fulfill the limits.

Date of Issue: 07/2011













## 4.4.8 Cruise

El.pump - OFF Refer to Section 5, for recommended cruising figures.

## 4.4.9 Descent

1. Optimum glide speed

65 KIAS

## CAUTION

It is not advisable to reduce the engine throttle control lever to minimum on final approach and when descending from very high altitude. In such cases the engine becomes under-cooled and a loss of power may occur. Descent at 4000 rpm, speed 75 KIAS, and check that the engine instruments indicate values within permitted limits.

Date of Issue: 07/2011













## 4.4.10 Before landing

- 1. Approach speed
- 2. Throttle
- 3. El. pump
- 4. Wing flaps
- 5. Trim
- 6. Propeller control
- 7. Autopilot

## - 65 KIAS (calm wind 55 KIAS)

- as needed, approximately 3500 RPM
- ON
- 20 degrees
- as needed
- ON
- OFF

## 4.4.11 Balked Landing

- 1. Throttle
- full power (max.5800 rpm)
- 2. Wing flaps extend as needed
- 3. Trim adjust as needed

Date of Issue: 07/2011



ST









- 4. Wing flaps
- retract at height of 150 ft after reaching 70 KIAS
- 5. Trim adjust
- 6. Repeat circle pattern

## 4.4.12 Landing

- 1. Touch-down on main wheels (Nose wheel is for taxiing only)
- 2. Apply brakes as needed after the nose wheel touch-down

## 4.4.13 After landing

- 1. Engine speed set as required for taxiing
- 2. Wing flaps retract

## 4.4.14 Engine shutdown



ST









- 1. Engine speed
- 2. Instruments
- 3. Avionics
- 4. Ignition
- 5. Propeller control
- 6. Circuit breakers
- 7. Master switch
- 8. Switch box
- 9. El. pump
- 10. Fuel Selector

- idle
- engine instruments within limits
- switch off
  - switch off one at a time
  - swtch off
  - switch off
    - switch off
    - turn key to switch off
  - off
  - off

## CAUTION

Rapid engine cooling should be avoided during operation. This happens above all during aircraft descent, taxiing, low engine rpm or at engine shutdown immediately after landing.

Date of Issue: 07/2011













Under normal conditions the engine temperatures stabilize during descent, taxiing and at values suitable to stop engine by switching the ignition off. If necessary, cool the engine at 2500 - 2750 rpm to stabilize the temperatures prior to engine shut down.













## 4.4.15 Aircraft parking and tie-down

- 1. Ignition check
- OFF
- 2. Master switch check - OFF
- 3. Fuel selector
- 4. Parking brake
- OFF
- 5. Canopy
- use it as necessary (if installed)
- close, lock as necessary
- 6. Secure the airplane
- NOTE

It is recommended to use parking brake (if installed) for short-time parking only, between flights during a flight day. After ending the flight day or at low temperatures of ambient air, do not use parking brake, but use the wheel chocks instead.

Date of Issue: 07/2011












### NOTE

Use anchor eyes on the wings and fuselage rear section to fix the airplane. Move control stick forward and fix it together with the rudder pedals. Make sure that the cockpit canopy is properly closed and locked. The anchoring before leaving the airplane is important if the airplane is not equipped with a parking brake.













### 4.4.16 Flight in rain

When flying in the rain, no additional steps are required. Aircraft qualities and performance are not substantially changed. However VMC must be maintained.













## **SECTION 5**

## 5. PERFORMANCE

- 5.1 Introduction
- 5.2 Performance
  - 5.2.1 Airspeed indicator system calibration
  - 5.2.2 Stall speeds
  - 5.2.3 Take-off performance
  - 5.2.4 Landing distances
  - 5.2.5 Climb performance
  - 5.2.6 Cruise

Date of Issue: 07/2011













- 5.2.7 Endurance and Range
- 5.2.8 Demonstrated crosswind performance
- 5.2.9 Optimum glide speed
- 5.2.10 Ceiling













## 5.1 Introduction

Section 5 provides data for airspeed calibration, stall speeds, take-off performance and additional information.

The presented data has been computed from actual flight tests with the aircraft and engine in good conditions and using average piloting techniques.

If not stated otherwise, the performance stated in this section is valid for maximum take-off weight and under ISA conditions.

The performance shown in this section is valid for aircraft fitted with given engine ROTAX 914 UL 113 hp and DUC propeller setted for static RPM on the ground 5100 rpm.













## 5.2 Performance

### 5.2.1 Airspeed indicator system calibration

KIAS	KCAS
27	27
32	32
37	37
43	43
48	48
54	54

Date of Issue: 07/2011













59	59
64	64
70	71
75	75
80	80
86	85
91	90
97	96
102	100
107	104
113	110

Date of Issue: 07/2011













118	114
123	119
129	124
134	129
140	134
145	138













#### 5.2.2 Stall speeds 29.95 feet long wing

Conditions: Max.take-off weight Engine idle run	Wing flaps pos.	KIAS	KCAS	Altitude loss at recovery [ft]
	0°	39	39	50
Wing level stall	20°	37	37	40
	30°	32	32	26
Co-ordinated turn 30° bank	<b>0</b> °	42	42	60
	20°	39	39	48

Date of Issue: 07/2011













30 33 33 36		30°	33	33	36
-------------	--	-----	----	----	----













### 5.2.2PW Performance wing aircraft Stall speeds

Conditions: Max.take-off weight Engine idle run	Wing flaps pos.	KIAS	KCAS	Altitude loss at recovery [ft]
	<b>0</b> °	45	45	60
Wing level stall	20°	42	42	50
	30°	39	39	40
	<b>0</b> °	48	48	70
	20°	45	45	60

Date of Issue: 07/2011



Aircraft Operating

Instructions











|--|

# 5.2.3 Take-off performance with performance 27'wing at sea level and gross weight with 10 degrees flap













RUNWAY SURFACE	Take-off run distance <i>[m]</i>	Take-off distance over 50 ft obstacle [m]
PAVED	250	400
GRASS	400	600













5.2.3LW Take-off performance with 29.95' long wing Bristell at sea level and gross weight with 10 degrees flap will be approximately 10% less the with the shorter performance wing.













### 5.2.4 Landing distances

RUNWAY SURFACE	Landing distance over 50 ft obstacle [m]	Landing run distance (braked) <i>[m]</i>
PAVED	300	200
GRASS	250	125













5.2.4LW Landing distances for long wing aircraft are approximately 10 % less.

5.2.5 Climb performance 27 foot wing-0 degrees flaps

Conditions: Max.Continuous Power – 5500 rpm	Best rate-of	-climb speed
Weight – 1320 lbs	KIAS	[fpm]
0 ft ISA	70	1050













3000 ft ISA	68	1000
6000 ft ISA	66	900
9000 ft ISA	64	800

5.2.5LW Climb performance 29.95 foot wing-0 degrees flaps will be about 5% better than with the 27 foot performance wing.













5.2.6 Cruise Rotax 914 UL Turbo Charges Engine and the 27 foot performance wing.

Altitude	Engine	Airspeed	
[ft ISA] speed [rpm]		KIAS	KTAS
	4500	95	95
	4800	104	102
0	5000	110	108
U	5300	119	115
	5500	123	119
	5800	NA	NA













	4500	94	94
	4800	105	103
2000	5000	112	109
3000	5300	118	114
	5500	125	121
	5800	NA	NA
	4500	85	85
	4800	92	92
6000	5000	100	98
	5300	108	105
	5500	119	115

Date of Issue: 07/2011













	5800	122	118
	5000	114	110
	5500	130	126
9000 12000	5800	134	130
	5300	124	120
	5500	131	127
	5800	140	135

5.26LW long wing aircraft will cruise about 3 knots slower than the performance 27 foot wing aircraft.

0.2.1.1

Endurance and Range with one hour reserves

Date of Issue: 07/2011













The table below shows fuel consumption, endurance and range

Altitude	[ft ISA]	6000 ft				
Fuel quantity	[U.S.gall]]	31.7				
Engine speed	[rpm]	4500	4800	5000	5300	5500
Fuel consumption	[U.S.gallo ns/hr]	3.0	5,00	5,5	6	7
Airopood	KIAS	85	92	100	108	119
Allspeed	KTAS	85	92	98	105	115

Date of Issue: 07/2011



Aircraft Operating

Instructions











Endurance	[hh:mm]	9;00	5;20	5:00	4:30	4:00
Range	[N.miles]	765	478	481	472	460
	[S.miles]	879	550	553	543	529

Demonstrated crosswind performance

Max. permitted head wind velocity

Max. permitted cross wind velocity

for take-off and landing .....15 KIAS

Long 29.95 foot wing demonstrated crosswind component is 14 KIAS.













### 5.2.9 Optimum glide speed

Optimum glide speed......60 KIAS

### 5.2.10 Ceiling

Service ceiling-27 foot wing...1,5000ft, with 29.95' wing-16,000ft

























# **SECTION 6**

## 6. WEIGHT AND BALANCE

- 6.1 Introduction
- 6.2 Weight and Balance Records
- 6.3 Permitted payload range

Introduction

This section contains the payload range within which the BRISTELL LSA may be safely operated.

Date of issue: 07/2011













Procedures for weighing the aircraft and the calculation method for establishing the permitted payload range are contained in last revision of FAA Aviation Advisory Circular AC.43.13 – 1B

### Weight and Balance Record

### **Equipment list:**

- Garmin G3X Touch
- Radio Garmin GTR 20
- Transponder GTX23 ES Mode S
- Intercom is built into the G3X
- Garmin 796 GPS
- DUC propeller
- elevator trim tabs

Date of issue: 07/2011













- Adjustable rudder pedals
- Dual brakes
- ELT KANAD Integra

### Weight and Balance report lists:

1. Empty CG check

Date of issue: 07/2011













2. Blank form

WEIGHT & BALANCE REPORT Empty Weight C.G. Check



























	ITEM	<b>WEIGHT</b> (lbs)	<b>ARM</b> (in)	<b>MOMENT</b> (WEIGHTxARM)
CG	RIGHT MAIN WHEEL	W <sub>R</sub> = 288,0	L <sub>R</sub> = 28,3	8150,4
IPTΥ	LEFT MAIN WHEEL	W <sub>L</sub> = 289,5	L <sub>L</sub> = 28,3	8192,8
AIRCRAFT EM	NOSE WHEEL	W <sub>N</sub> = 175,1	$L_N = -29,5$ (negative arm)	-5165,4
	COMPUTED CG	Empty Weight:	CG= 14,9 in	Aircraft moment:
	EMPTY	<i>W</i> <sub>E</sub> = 760 lbs	28,0 % MAC	11200,2

Date of issue: 07/2011













	WEIGHT (lbs)	ARM (in)	<b>MOMENT</b> (WEIGHTxARM)
PILOT		23,6	
PASSENGER		23,6	
BAGGAGE COMPARTMENT		78,7	
FUEL TANKS		7,87	
TOTAL	W=		М=
Take-Off Weight:			CG= in % MAC

Max.Take-off Weight: 1320 lbs

Date of issue: 07/2011













CG Range: 25 - 35 %

Forward limit: 13,3 in

Rearward limit: 18,6 in

Serial No: 032/2013

Date: 27.12.2012

By: Milan Bristela

 Total Moment
 100

 Center of Gravity (CG) =
 [m] x
 [%]

 Total Weight
 MAC

Date of issue: 07/2011













WEIGHT & BALANCE REPORT Forward C.G. Check

Date of issue: 07/2011

Revision: 1.0

6-9



























	ITEM	WEIGHT (lbs)	ARM (in)	<b>MOMENT</b> (WEIGHTxARM)
	RIGHT MAIN WHEEL	W <sub>R</sub> = 288,0	L <sub>R</sub> = 28,3	8150,4
MPTY	LEFT MAIN WHEEL	$W_{L}=289,5$	L <sub>L</sub> = 28,3	8192,8
C&G OF E WEIGHT AIR	FRONT WHEEL	W <sub>N</sub> = 175,1	$L_N = - 29,5$ (negative arm)	-5165,4
	CALCULATED	Empty weight:	CG= 14,9 in	Aircraft moment:
	EMPTY C&G	W== 760 kg	<b>28,0</b> % SAT	11200,2

Date of issue: 07/2011













	WEIGHT (lbs)	ARM (in)	<b>MOMENT</b> (WEIGHTxARM)
PILOT	121,3	23,6	2864,8
PASENGER		23,6	
LUGGAGE -FUSELAGE		78,7	
WING LOCKERS		24,8	

Date of issue: 07/2011


Instructions











FUEL TANKS	211,7	7,87	1666,8
TOTAL	W= 1085,6		M= 15731,7
TAKE OFF WEIGHT:	1085,6		CG= 27,3 v % SAT

Max. take off weight: 1320 lbs

C&G RANGE: 25- 35 %

Serial No.: 032/2013
Date: 27.12.2012
By: Milan Bristela













Total moment100Center of gravity( C&G) = ------ [ in ] x------ [%]Total weightSAT













WEIGHT & BALANCE REPORT Rearward C.G. Check

Date of issue: 07/2011

















Instructions











	ITEM	WEIGHT (lbs)	ARM (in)	<b>MOMENT</b> (WEIGHTxARM)	
	RIGHT MAIN WHEEL	W <sub>R</sub> = 288,0	L <sub>R</sub> = 28,3	8150,4	
C&G OF EMPTY AIRCRAFT	LEFT MAIN WHEEL	$W_{L}=289,5$	L <sub>L</sub> = 28,3	8192,8	
	FRONT WHEEL	W <sub>N</sub> = 175,1	$L_N = -29,5$ (negative arm)	-5165,4	
	CALCULATED EMPTY C&G	Empty weight:	<b>CG</b> = 14,9 in	Aircraft moment :	
		W <sub>E</sub> = 760 lbs	28,0 <b>%</b> SAT	11200,2	

Date of issue: 07/2011



Instructions











	WEIGHT (lbs)	ARM (in)	<b>MOMENT</b> (WEIGHTxARM)
PILOT	209,5	23,6	4948,2
PASENGER	209,5	23,6	4948,2
LUGGAGE - FUSELAGE	8,8	78,7	694,5
WING LOCKERS	66,2	24,8	1640,7
FUEL TANKS	33,1	7,87	260,4
TOTAL	W= 1279,6		<i>M</i> = 23692,2
Take off weight:	1279,6 lbs		CG= 34,8 % SAT

Date of issue: 07/2011













Max. take off weight: 1320 lbs

C&G range: 25 - 35 %

Center of gravity (**CG**) =  $\begin{array}{c} Total moment \\ \hline Total weight \end{array} \begin{bmatrix} in \end{bmatrix} \times \begin{array}{c} 100 \\ \hline SAT \end{bmatrix}$ 

Date of issue: 07/2011













WEIGHT & BALANCE REPORT Empty form

Date of issue: 07/2011



























	ITEM	WEIGHT (lbs)	ARM (in)	<b>MOMENT</b> (WEIGHTxARM)
	RIGHT MAIN WHEEL	W <sub>R</sub> =	L <sub>R</sub> =	
MPTY FT	LEFT MAIN WHEEL	$W_L =$	L <sub>L</sub> =	
OF EI RCRA	FRONT WHEEL	W <sub>N</sub> =	L <sub>N</sub> = - (negative arm)	-
C&G AI	CALCULATED	Empty weight:	CG= v	Aircraft moment:
	EMPTY C&G	W <sub>E</sub> =	% SAT	

Date of issue: 07/2011













	WEIGHT (lbs)	ARM (in)	<b>MOMENT</b> (WEIGHTxARM)
PILOT		23,6	
PASSENGER		23,6	
LUGGAGE - FUSELAGE		78,7	
WING LOCKERS		24,8	

Date of issue: 07/2011



Aircraft Operating

Instructions











FUEL TANKS		7,87	
TOTAL	<i>W</i> =		М=
Take off weight:	lbs		<b>CG=</b> v % SAT

Max. take off weight: 1320 lbs

Rozpětí těžiště: 25 – 35 %

Date of issue: 07/2011













#### Max. useful load :

 $W_{U.} = 1320 \text{ lbs} - W_{EMPTY}$  $W_{U.} = 1320 \text{ lbs} - = \text{lbs}$ 

Do not exceed maximum take-off weight 1320 lbs !

 Total moment
 100

 Center of gravity (**CG**) = ------ [ in ] x ------ [ % ]

Date of issue: 07/2011

Revision: 1.0

6-2



Instructions











SA

Total weight

6.3 Permitted	payload	range

	Permitted payload range of BRISTELL SN: 032/2013								
F	GAUGE		60 min	1/4	1/2	3/4	1		
U	VOLUME	USgal	3,17	7,91	15,83	23,74	31,66		
Е		(litres)	12	30	60	90	120		
L		lbs	18,9	48,4	96,8	145,2	193,6		
	WEIGHT	(kg)	8,6	22	44	66	88		
	Permitted crew weight								

Date of issue: 07/2011



Instructions

ST









	NO BAGGAGE		lbs	557	528	480	431	383
	0 lb	(0 kg)	(kg)	253	239	217	196	174
	1/2 REAR		lbs	541	511	463	415	366
	16,5 lbs	(7,5 kg)	(kg)	245	232	210	188	166
	REAR		lbs	506	491	446	401	356
В	33 lbs	(15 kg)	(kg)	230	223	202	182	162
Α	1/2 WING	LOCK	lbs	502	487	442	397	352
G	44 lbs	(20 kg)	(kg)	228	221	201	180	160
G	1/2 REAR+	1/2 WING	lbs	482	467	422	377	332
Α	60,5 lbs	(27,5 kg)	(kg)	219	212	192	171	151

Date of Issue: 07/2011













G	REAR+1/2 WING		lbs	462	447	402	357	312
Е	55 lbs	(35 kg)	(kg)	210	203	182	162	142
	WING LOCK		lbs	458	443	398	353	308
	<b>88 lbs</b> (40 kg)		(kg)	208	201	181	160	140
	1/2 REAR+WING		lbs	438	423	378	333	288
	<b>104,5 lbs</b> (49 kg)		(kg)	199	192	172	151	131
	REAR+WING		lbs	418	402	358	313	268
	<b>121 lbs</b> (58 kg)		(kg)	190	182	162	142	122
Cre	w weight=Max.	Take-offweight	- Empty w	reight - Ba	ggage w	eight - Fu	el weight	

\* This weight values are determined with regard on rear CG range.

Date of Issue: 07/2011













# **SECTION 7**

## 7. AIRPLANE AND SYSTEMS DESCRIPTION

- 7.1 Introduction
- 7.2 Airframe
- 7.3 Control System
- 7.4 Landing Gear
- 7.5 Seats and Safety harness
- 7.6 Baggage Compartment

Date of Issue: 07/2011













7.7 Canopy

### 7.8 Powerplant

- 7.9.1 Throttle and Choke
- 7.9.2 Carburetor pre-heating
- 7.9.3 Heating
- 7.9 Fuel system

### 7.10 Electrical system

- 7.11.1 Battery
- 7.11.2 Master switch
- 7.11.3 Ignition
- 7.11.4 Starter button

Date of Issue: 07/2011













- 7.11 Pitot and Static Pressure System
- 7.12 Miscellaneous Equipment
- 7.13 Instruments and Avionics
- 7.14 Cockpit
  - 7.4.1 Photo of the cockpit
  - 7.4.2 Description of equipment and controls in the cockpit













### 7.1 Introduction

This section provides description and operation of the aircraft and its systems.

### 7.2 Airframe

All-metal construction, single curvature metal skins riveted to stiffeners. Construction is of 6061-T6 aluminum sheet metal riveted to aluminum angles with Avex rivets. This high strength aluminum alloy construction provides long life and low maintenance costs thanks to its durability and corrosion resistance characteristics.

The wing has a high lift airfoil equipped by fowler flaps controlled by the electric servo operated by the pilot.













### 7.3 Control system

The plane is equipped with a dual stick control and classic rudder pedals, with pedal hydraulic brakes for easy ground control of the steerable nose wheel.

The elevator and aileron trim control, as well as wing flaps are electrically operated from the rocker switches located on the instrument panel or on the control stick.













### 7.4 Landing gear

Tricycle landing gear with the castering nose wheel. Main landing gear uses two fiberglass spring elements.

### 7.5 Seats and safety harness

Side-by-side seating. Seat cushions are removable to make easier cleaning and drying. Four point safety belts provided to each seat.. Optional, is additional seat upholstery to raise the small pilot or move him forward.

#### NOTE

Prior to each flight, ensure that the seat belts are firmly secured to the airframe, and that the belts are not damaged. Adjust the buckle so that it is centered on the body.

Date of Issue: 07/2011













### 7.6 Baggage compartment

The rear baggage compartment is located behind the seats. It may accommodate up to 33 lbs. This space is divide on two sections – baggage compartment A and B. Is not recommended give too heavy things into baggage compartment B.

The baggage may also be loaded into the baggage compartment inside each wing up to 44 lbs, in each wing locker.

Make sure that baggage does not exceed maximum allowable weight, and that the aircraft CG is within limits with loaded baggage.

All baggage must be properly secured.













### 7.7 Canopy

Access to the cabin is from both sides. Make sure that the canopy is latched and mechanism is securely locked into position on both sides before operating the aircraft.

### 7.8 Powerplant

#### Engine:

ROTAX 914UL Turbo Charged engine 113 hp is installed on BRISTELL LSA. Rotax 914 UL is 4-stroke, 4 cylinder, horizontally opposed, spark ignition engine with one central camshaft-push-rod-OHV. Liquid cooled cylinder heads, ram air cooled cylinders.

Dry sump forced lubrication. Dual contactless capacitor discharge ignition. The engine is fitted with an electric starter, AC generator and

Date of Issue: 07/2011













mechanical fuel pump. Prop drive via reduction gear with integrated shock absorber.

#### **Propeller:**

• DUC 1580/3R on ground adjustable.

**NOTE** For technical data refer to documentation supplied by the propeller manufacturer

#### 7.8.1 Throttle and Choke

Engine power is controlled by means of the THROTTLE lever. THROTTLE lever and CHOKE lever are positioned in the middle channel

Date of Issue: 07/2011













between the seats side by side. Both levers are mechanically connected (by cable) to the flap on the carburetors. Springs are added to the throttle push rods to ensure that the engine will go to full power if the linkages fail.

#### 7.8.2 Carburetor pre-heating

The control lever is installed on the instrument panel.

#### 7.8.3 Heating

Heating consists of a heat exchanger on the exhaust manifold and control mechanism located on the right hand side of instrument panel.

#### CAUTION

Incidents involving exhaust gases entering the heating or ventilation system may result in fatal accidents due to carbon monoxide

Date of Issue: 07/2011













poisoning of the aircraft occupants. A carbon monoxide detector is recommended.













### 7.9 Fuel system

Wing tanks volume 2 x 15.7 U.S. gallonsEach tank is equipped with a vent outlet and screen filter.Drain valve located in the lowest point of the each tank and on the bottom edge of the firewall, on the gascolator.Main fuel selector valve is on the central console in the cockpit.

The electric fuel pump is located on firewall.

#### CAUTION

Do not overfill the tanks to avoid fuel overflow through venting tubes.

## 7.10 Electrical system

Date of Issue: 07/2011













#### 7.10.1 Battery

The battery is mounted on the forward side of the firewall.

#### 7.10.2 Master switch

Master switch connects the electrical system to the 12 Volt battery and charger/coils, controlled by the regulator. See Engine Manual for electrical system details.

#### NOTE

Ignition system is independent on the power source and will operate even with Master switch and/or breaker off.

#### 7.10.3 Ignition Switch

Ignition must be on BOTH to operate the engine: For safety, remove key when engine is not running.













#### NOTE

All switches and or engine controls are "up" or "push forward" for operation, except the choke, cabin heat and carburetor pre-heat, which is "Pull" for "on". Optional equipment, switches and/or fuses are subject to change or installed as requested. See Aircraft Equipment List and Photo and Description of equipment and controls in the cockpit.

### 7.11 Pitot and static pressure system

Heated Pitot Tube is located below the left wing. Pressure distribution to the instruments is through flexible plastic hoses. Static port is located in fuselage under the luggage compartment.

Keep the pitot head clean to ensure proper function of the system.

Date of Issue: 07/2011













### 7.12 Miscellaneous equipment

- Adjustable pedals
- Heating
- Wheel pants
- Airplane cover
- Tow bar

Date of Issue: 07/2011













### 7.13 Instruments and Avionics

- Dual Garmin G3X Touch ten inch PFD's
- Garmin GTR 20 remote COM + antenna
- Garmin GTX 23 ES mode S Transponder
- GPS GARMIN 796
- Garmin Gmc 305 Autopilot control
- With Altitude hold, GPS steering, FD,
- ELT KANAD Integra
- 12 V Socket

NOTE

Date of Issue: 07/2011













For operating instructions refer to the documentation supplied with the instruments.













7.14 Cockpit













# **SECTION 8**

## 8. AIRPLANE HANDLING, SERVICING AND MAINTENANCE

- 8.1 Introduction
- 8.2 Aircraft Inspection Periods
- 8.3 Aircraft Alterations or Repairs
- 8.4 Ground Handling
  - 8.4.1 Towing

Date of Issue: 07/2011













- 8.4.2 Parking
- 8.4.3 Mooring
- 8.4.4 Jacking
- 8.4.5 Road transport
- 8.5 Cleaning and Care












## 8.1 Introduction

This section contains factory-recommended procedures for proper ground handling and servicing of the airplane. It also identifies certain inspection and maintenance requirements, which must be followed if the airplane is to retain that new-plane performance and dependability.

## 8.2 Aircraft inspection periods

Periods of overall checks and contingent maintenance depends on the condition of the operation and on overall condition of the airplane. Inspections and revisions should be carried out in the following periods, at least:

- a) after the first 25 flight hours
- b) after every 50 flight hours
- c) after every 100 flight hours or at least annual inspection













Refer to the Engine Operator's Manual for engine maintenance. Maintain the prop according to its manual.

All repairs and maintenance should be made in accordance with AC 43.13-1B.

## 8.3 Aircraft alterations or repairs

It is recommended to contact the airplane manufacturer prior to any alternations to the aircraft to ensure that the airworthiness of the aircraft is not violated. Always use only the original spare parts produced by the airplane (engine, prop) manufacturer.

If the aircraft weight is affected by that alternation, a new weighing is necessary, then record the new empty weight into the Weight and Balance record / Permitted payload range in SECTION 6 and up-date the placard showing weights in the cockpit.













## 8.4 Ground handling

#### 8.4.1 Towing

To handle the airplane on the ground, use the Tow Bar, or the fuselage rear pushed down in the place of a bulkhead.

#### CAUTION

Avoid excessive pressure at the airplane airframe-especially at control surfaces. Keep all safety precautions, especially in the propeller area.

#### 8.4.2 Parking

It is advisable to park the airplane inside a hangar or alternatively inside any other suitable space (garage) with stable temperature, good ventilation, low humidity and dust-free environment.

Date of Issue: 07/2011













It is necessary to moor the airplane when it is parked outside a hangar. Also when parking for a long time, cover the cockpit canopy, possibly the whole airplane by means of a suitable tarpaulin.

#### 8.4.3 Mooring

The airplane should be moored when parked outside a hangar after the flight day. The mooring is necessary to protect the airplane against possible damage caused by wind and gusts.

For this reason the aircraft is equipped with mooring eyes located on the lower surfaces of the wings.

Mooring procedure:

1. Check: Fuel Selector shut off, Circuit breakers and Master switch switched off, Switch box switched off.













- 2. Fix the hand control using e.g. safety harness
- 3. Close air vent
- 4. Close and lock canopy
- Moor the aircraft to the ground by means of a mooring rope passed through the mooring eyes located on the lower surfaces of the wings and below rear fuselage

#### NOTE

In the case of long term parking, especially during winter, it is recommended to cover the cockpit canopy or possibly the whole aircraft by means of a suitable tarpaulin attached to the airframe.

#### 8.4.4 Jacking

Date of Issue: 07/2011













Since the empty weight of this aircraft is relatively low, two people can lift the aircraft easily.

First of all prepare two suitable supports to support the aircraft.

It is possible to lift the aircraft by handling the following parts:

- By pushing the fuselage rear section down in the place of a bulkhead the fuselage front section may be raised and then supported under the firewall.
- By holding the fuselage rear section under a bulkhead the fuselage rear may be raised and then supported under that bulkhead.
- To lift up a wing, push from underneath that wing <u>only</u> at the main spar area. Do not lift up a wing by handling the wing tip.













#### 10.4.5 Road transport

The aircraft may be transported after loading on a suitable car trailer. It is necessary to dismantle the wings before road transport. The aircraft and dismantled wings should be attached securely to protect these parts against possible damage.

#### 8.5 Cleaning and care

Use efficient cleaning detergents to clean the aircraft surface. Oil spots on the aircraft surface (except the canopy!) may be cleaned with gasoline.

The canopy may only be cleaned by washing it with a sufficient quantity of lukewarm water and an adequate quantity of detergents. Use either a













soft, clean cloth sponge or deerskin. Then use suitable polishers to clean the canopy.

#### CAUTION

Never clean the canopy under "dry" conditions and <u>never</u> use gas or chemical solvents!

Upholstery and covers may be removed from the cockpit, brushed and eventually washed in lukewarm water with an adequate quantity of detergents. Dry the upholstery thoroughly before insertion into the cockpit.

#### CAUTION

In the case of long term parking, cover the canopy to protect the cockpit interior from direct sunshine.

Date of Issue: 07/2011













# **SECTION 9**

# 9. REQUIRED PLACARDS AND MARKINGS

9.1 Limitation placards9.2 Miscellaneous placards and markings

Date of Issue: 07/2011













## 9.1 Limitation placards

The airplane must be placarded with:

- All fuses
- Ignition switches
- Choke
- Starter
- Trim: Nose UP and Tail DOWN
- Flaps: 0°, 10°, 20°, 30°
- Maximum rear baggage weight 33 lbs
- Maximum weight in each wing locker 44 lbs, if installed
- Instruments
- Canopy: Open Close

Date of Issue: 07/2011













- Fuel capacity: 17,17 U.S. gallons / min. 93 Octane at filler neck
- Fireproof Identification plate to be affixed to the aircraft in a prominent position near the main point of entrance to the aircraft (plate must show required information)













## 9.2 Miscellaneous placards and markings

PASSENGER WARNING! THIS AIRCRAFT WAS MANUFACTURED IN ACCORDANCE WITH LIGHT SPORT AIRCRAFT AIRWORTHINESS STANDARDS AND DOES NOT CONFORM TO STANDARD CATEGORY AIRWORTHINESS REQUIREMENTS.

Date of Issue: 07/2011













# NO INTENTIONAL SPINS! AEROBATICS PROHIBITED!

MAX. BAGGAGE WEIGHT: 33 lbs

MAX.WEIGHT IN WING LOCKER: 44

Unusable fuel quantity 0,13 U.S. gallons

Date of Issue: 07/2011













ENGINE RPM Max. take-off(max. 5 min.) 5800 rpm Max. continous 5500 Stan wro naps 39 kts

> WARNING DO NOT EXCEED MAXIMUM TAKE-OFF WEIGHT: 1320 LB

> WARNING IFR FLIGHTS AND INTENTIONAL FLIGHTS UNDER ICING CONDITIONS ARE PROHIBITED!

Date of Issue: 07/2011













PASSENGER NOTICE THIS AIRCRAFT CONFORMS TO ASTM CONSENSUS STANDARDS OF AIRWORTHINESS DEVELOPED AND MAINTAINED BY THE AVIATION COMMUNITY UNDER ASTM TECHNICAL COMMITTEE F37.

# **NO STEP**

NO PUSH

Date of Issue: 07/2011













FUEL CAPACITY: 17.17 US gallons / 93 OCTANE

OILSAE 5W-40 or Equivalent











Date of Issue: 07/2011















✓ PEDAL SETTING

Date of Issue: 07/2011





























Date of Issue: 07/2011













**BAGGAGE COMPARTMENT - B** 













If BRS rescue system is installed:

Date of Issue: 07/2011















- located on the both sides of fuselage













- located in place rocket



Revision: 1.0

Date of I













#### CAUTION

The owner (operator) of this airplane is responsible for the readability of placards during the aircraft service life.

























# **SECTION 10**

# 10. SUPPLEMENTS

## 10.1 Introduction

## 10.2 List of Inserted Supplements

## 10.3 Inserted Supplemets













#### 10.1 Introduction

This section contains the appropriate supplements necessary to safely and efficiently operate the aircraft when equipped with various optional systems and equipment not provided with the standard airplane.

## 10.2 List of inserted supplements

Date	Suppl. No.	Title of inserted supplement
08/2011	01/2011	Aircraft Flight Training Supplement
08/2011	02/2011	Description of the aircraft S/N 032/2013

Date of Issue: 07/2011













Date	Suppl. No.	Title of inserted supplement

Date of Issue: 07/2011













Date	Suppl. No.	Title of inserted supplement













Date	Suppl. No.	Title of inserted supplement













Date	Suppl. No.	Title of inserted supplement













Date	Suppl. No.	Title of inserted supplement













# 10.3 Inserted Supplemets: SUPPLEMENT No. 01/2012













# Aircraft Flight Training Supplement

The BRISTELL LSA flying characteristics and behavior are similar to single engine aircraft.

Following training procedure is applicable if the pilot is holder of UL, PPL or LSA Pilot License. The training flight hours are recommended minimum and depends on the Flight Instructor if student pilot is ready to continue on in next training step. Training can be performed by Flight Instructor or by the experienced pilot who has minimum 20 hours on the BRISTELL LSA.

Type Rating Training Procedure:

Date of Issue: 07/2011













**Ground Training** - before practical Flight Training the pilot has to get familiar with following procedures and documentation

- Aircraft Operating Instructions (AOI)
- Aircraft Maintenance and Inspection Procedures
- Aircraft preflight inspection procedure
- Control Checklists
- Radio, avionics, aircraft and engine controls procedures
- Differences in control and aircraft handling
- Emergency procedures












Flight training program - recommended

Flight Training Procedure		Dual		Solo	
		Flights	hr/min	Flights	hr/min
1.	Check flight	1	30'		
2.	Pattern training flights up to 1000 ft AGL	4	20'	3	15'
3.	Pattern training flights up to 500 ft AGL	4	20'	3	15'
4.	Stall speed, 45°turns, side slips	1	30'	1	20'

Date of Issue: 07/2011

Revision: 1.0

10-11













5.	Emergency landing training	4	20'	3	10'
Total		14	2 hr	10	1 hr













Flight Training Procedure - description

- 1. Check flight Student Pilot will fly the airplane in local flight, instructor is giving advice as necessary.
- 2. Pattern training flights up to 1000 feet AGL high pattern procedures, instructor is giving advice as necessary.
- **3.** Pattern training flights up to 500 feet AGL high pattern procedures, instructor is giving advice as necessary.
- **4. Stall speed, 45° turns, sideslips** stall speed flaps retracted and extended (landing configuration), sideslips at landing configuration.
- **5. Emergency landing training** emergency procedures and landing to 1/3 of runway.

Date of Issue: 07/2011

Revision: 1.0

10-13













#### Note:

During solo flights instructor is observing the student pilot on pattern and can advise by radio as necessary.

#### Endorsement:

Instructor will endorse the Type Rating to the Pilots Logbook, if required.













# SUPPLEMENT No. 02/2012

# **AIRCRAFT DESCRIPTION**

Date of Issue: 07/2011













Registration : N

Serial number:

This Supplement must be contained in the Aircraft Operating Instructions during operation of the airplane.

Date of Issue: 07/2011













Information contained in this Supplement add or replace information from the basic Aircraft Operating Instructions in the further mentioned parts only. Limitations, procedures and information not mentioned in this Supplement are contained in the basic Aircraft Operating Instructions.

# 0. TECHNICAL INFORMATION

This Supplement adds information necessary for airplane operation with equipment installed in the airplane BRISTELL LSA of S/N 032/2013.

Date of Issue: 07/2011













#### 0.1 Record of revisions

No changes.

### 1. GENERAL INFORMATION

No changes.

# 2. OPERATING LIMITATION

### 2.4.3 Oil

#### NOTE: Type of oil used by aircrafts manufacturer :

Aeroshell OIL SPORT PLUS 4

### 2.4.4 Coolant

Date of Issue: 07/2011













NOTE: Type of coolantl used by aircrafts manufacturer : DEX-COOL 50/50 Mixture ratio coolant / water 50/50 [%] Max. CHT temperature : 275°F

# 3. EMERGENCY PROCEDURES

No changes.

# 4. NORMAL PROCEDURES

No changes.

Date of Issue: 07/2011













# 5. PERFORMANCE

No changes.

# 6. WEIGHT AND BALANCE

No changes.

# 7. AIRPLANE AND SYSTEMS DESCRIPTION No changes.

# 8. AIRPLANE HANDLING, SERVICING AND MAINTENANCE

No changes.

Date of Issue: 07/2011























